

INSTRUCTIONS FOR USING E-Z UP AND KD SIDEWALLS

For ease of installation we suggest that you install your sidewalls with the canopy raised to the first snap-button stop – when conditions permit.

1. Roll up the canopy top at the four corners.
2. Unfold sidewall being sure that the brass grommets are at the bottom and the long sections of the roll-up straps are facing to the inside of the canopy. Be sure that the sidewall is outside of the scissor framework.
3. Attach the (short) velcros on the top edge of the wall to the “X” of the framework.
4. Attach the long Velcro straps at the legs by passing the Velcro over the plastic fitting at the top of the leg so that the top edge of the wall is just below the bottom of the Velcro on the canopy leg (that secures the roof fabric).
5. Secure the center Velcro strap by passing it over the plastic fitting at the top of the framework that is perpendicular to the wall – such that the top edge of the wall is a straight line from leg to leg.
6. Re-attach the short Velcros to the “X” on each side – again to maintain a straight line from leg to leg.
7. Fold down the canopy corners to their original position.