

INSTRUCTIONS ON HOW TO MAKE A 7' WIDE CONVERTIBLE EZ up MESH PANEL

1. Using needle nose pliers, pull out the 56 1/2" long piece of aluminum flat bar from the top and bottom edges on the side of your mesh panel where the rear door will be.
2. Using a hacksaw, cut through both flat bar pieces 23 1/4" from the end. This should leave you with two 33 1/4" pieces and two 23 1/4" pieces. Use a small file or sandpaper to smooth the cut edges.
3. Put the 23 1/4" pieces back in the top and bottom edges first, then put the 33 1/4" pieces in both edges.
4. Follow instructions for setting up an 8' wide Convertible Mesh Panel Wall.