

Upper StaBar Set

Instructions for Use

Parts:

- (1) Long Barrel Upper Ell
- (1) Upper Ell
- (2) Long/Short Upper 3 Way
- (3) Male pole sections – 61" long
- (3) Female pole sections – 54 ¼" long, Coded RED
- (7) Thumbscrews
- (2) Ball Bungees for bundling poles



Long Barrel Ell



Ell



Long/Short 3 Way

1. While setting up the TrimLine Canopy: Slide Upper StaBar joints onto top sections of legs (black arrows pointing down). Each rear leg should have a Long/Short 3 Way on it and each front leg should have an Ell Joint on it. Arrange legs such that the Long barrel Ell is facing the short barrel of the 3 Way joint and the shorter Ell is facing a long barrel of the other 3 Way joint.

2. Complete set up of canopy. Once legs heights have been adjusted for level you are ready to install the StaBar poles.

3. Assemble 3 StaBar poles by clicking together the male and female pole sections.

4. Install StaBar poles by sliding the color-coded end into a long barreled joint as far as possible. Now move to the other end of the pole and slide the pole back into the short barreled joint until you are able to snap it into place. Repeat with two remaining poles.

5. Finger tighten all thumbscrews on StaBar joints.