

# Banner Frame Offset from Canopy Legs

## Assembly Instructions

### Parts

- (2) Large Diameter LD202 Joints
- (4) Ell Joints I602G
- (2) Double Snap Button poles – 10" long
- (2) Riser pole sections – 32" long
- (1) Male pole section – 61" long
- (1) Female pole section – 58 ¼" long
- (8) Thumbscrews



Large Diameter  
LD202 Joint



Ell Joint I602G

### Assembly

1. **While assembling the canopy frame:** Slide Large Diameter LD202 Joints onto the top sections of the canopy legs, with the arrow pointing down.
2. Attach 10" Poles to LD202 Joints.
3. Attach two of the I602G Ell Joints to the ends of the 10" poles with the open barrel facing upwards.
4. Place riser pole sections into Ell Joints.
5. Connect the male and female pole sections to form a 116 ½" long pole. Attach an Ell Joint to each end of this pole.
6. Attach Ell Joints on ends of 10' long pole to the top ends of the riser poles to complete Banner Frame.
7. Finger-tighten thumbscrews in joints to stabilize frame.

