

Mesh Panel Display Walls for the E-Z UP and other Pop-up Canopies

For “1 Diamond” style frames

Parts:

- (3) 115” wide Mesh Panels for E-Z Up
- (1) Vinyl Carry Bag

***NOTE:** Carry bag is designed to keep your panels clean.

Do not use carry bag for storing or carrying poles or parts.


Before hanging your Mesh Panel Display Walls, you'll need to install the StaBar stabilizing bars on your E-Z Up or other pop-up canopy. Follow separate instruction included with StaBars.

IMPORTANT: If you will be using *ProGallery* covers on your Mesh Panels, you must hang the panels with the Velcro-edged side facing inwards. Otherwise, face the Velcro-edged side outwards.


1. Unroll a panel so that you are holding all six metal hooks at the top edge, keeping the panel folded once.
2. Attach two of the hooks to the E-Z Up frame. (You will not be using the center hook on each half.)

* If you are installing the panels using an Upper StaBar Kit on your pop-up tent, all hooks will be used. Attach three hooks, then unfold panel and attach remaining hooks to StaBar pole. Skip to step 5.

**The first time you hang the panels on the Upper StaBars, you will need to tap the hooks at the ends gently with a hammer to fit them over the corner joints of the StaBar Kit..



3. Now unfold panel and attach two hooks on the other half.




-detail of center of panel-


4. Wrap top buckle straps around the “X” of the roof frame, and click together. **Do not pull tightly** as this will raise the hooks off of the framework.

5. Now wrap Velcro straps at sides around the legs, pulling the panel taut as you go. Begin with the top two straps on each side, then attach the bottom pairs.


6. Finish attaching the panel by buckling straps at bottom edge of panel to the lower horizontal StaBar, pulling snug to smooth the panel.



top buckle strap



bottom buckle straps



side Velcro strap



The specially woven and heat-treated mesh of your Mesh Panels will support items up to 15 pounds using a pair of S-hooks (we recommend using 2 hooks for every item, regardless of weight, for secure hanging). For heavier or bulkier items, use our Straphangers (find them online at www.flourish.com)

***Remember to use your carry bag for the panels only! Do not use for storing or carrying poles or parts.**